

Menu structure

Beverage settings

- select ingredients
- beverage selection
- strength and quantity
- adjust the ingredient name
- beverage prices

Machine settings

- language
- date and time
- quick menu
- PIN-code settings
- special functions
- payment device

Process settings

- boiler temperature
- water filter
- energy-saving mode
- waste bin counter
- cleaning management
- descaling management

Multimedia

- manage screensaver
- adjust background
- adjust beverage images
- adjust beverage names
- display brightness
- sound

Maintenance

- counter readings
- rinsing machine
- cleaning brewer
- descale
- position brewer shaft
- replace water filter
- cleaning instructions

Service

- calibration
- software and settings
- machine information
- error history
- venting high-pressure pump
- put the machine out of operation
- input test
- output test
- cleaning history



Engels